



Thank you and congratulations on your recent purchase. Please take time reading and understanding the manual before operating the equipment. Fill in the following information, so that it is at hand when needed.

MODEL \_\_\_\_\_ SERIAL NO.



**WARNING** DATE OF PURCHASE

\*\*\*The operator must carefully read and follow any warnings, safety sign and instructions provided with or located on the equipment. \*\*\*

\*\*\*Please keep a copy of the manual in the cab so that it may be consulted by the operator. \*\*\* \*\*\*Do not allow untrained operators to use this equipment as serious injury, death or equipment damage could result. \*\*\*

#### **SIGNAL WORDS & DEFINITIONS**

\*SYMBOLS USED IN THE MANUAL AND ON THE MACHINERY\*

	SAFETY ALERT SYMBOL USED TO ALERT OF POTENTIAL PERSONAL INJURY HAZARDS. OBEY ALL SAFETY MESSAGES THAT FOLLOW THIS SYMBOL TO AVOID POSSIBLE INJURY OR DEATH. DANGER INDICATES A HAZARDOUS SITUATION
<b>A</b> DANGER	WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.
	WARNING INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.
	CAUTION USED WITH THE SAFETY ALERT SYMBOL, INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN MINOR OR MODERATE INJURY.
NOTICE	NOTICE IS USED TO ADDRESS PRACTICES NOT RELATED TO PERSONAL INJURY.



# A WARNING SYMBOL INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN SERIOUS INJURY OR DEATH.

**WARNING** DO NOT OPERATE MACHINERY WITHOUT READING AND UNDERSTANDING THIS MANUAL. FAILURE TO FOLLOW THIS INFORMATION CAN LEAD TO MACHINE DAMAGE, SERIOUS INJURY, OR EVEN DEATH.

**WARNING** USE ALL MACHINERY FOR ITS INTENDED USE. FAILURE TO FOLLOW THIS

INFORMATION CAN LEAD TO MACHINE DAMAGE, SERIOUS INJURY, OR EVEN DEATH.

**AWARNING** DO NOT MODIFY EQUIPMENT. FAILURE TO FOLLOW THIS INFORMATION CAN LEAD TO MACHINE DAMAGE, SERIOUS INJURY, OR EVEN DEATH.

**AWARNING** ANY MISS USE OR MODIFICATION TO THE EQUIPMENT CAN LEAD TO MACHINE DAMAGE, SERIOUS INJURY, OR EVEN DEATH.

**WARNING** DO NOT RIDE ON MACHINERY. FAILURE TO FOLLOW THIS INFORMATION CAN LEAD TO MACHINE DAMAGE, SERIOUS INJURY, OR EVEN DEATH.

#### **IMPORTANT SAFETY INFORMATION**

#### TO THE OPERATOR

Prior to using the TARCO® Lowlander Spreader you must be properly trained in the full operation of the machine. This would include but not be limited to a complete review of the operating and safety manual and a complete understanding of all safety procedures including the safety decals and information on the machine. If there is something you do not understand, ask your supervisor to explain it to you. If you require additional manuals or decals, please contact your dealer or the manufacturer.

Make sure all the manufacturers' protective guards, shields, and screens are in good repair, in place, and securely fastened. Damaged, missing, or weakened safety components can create a hazardous situation for the operator. NEVER remove or modify any safety components on this equipment.

Wear all the protective clothing and personal safety devices issued to you or called for by the job conditions. This may include but is not limited to a hard hat, safety shoes, safety glasses or goggles, heavy gloves, hearing protection, reflective clothing or wet weather gear. Remember, you are responsible for your safety and that of your co-workers. Good safety practices protect you and the people around you.

NEVER ride on any part of the equipment when operating the machine or at any time. Never modify the machine for riders in any way. Prior to operating this machine, be certain that all operators can ride safely in the truck or vehicle being used to trailer the machine. If your machine has been altered to accommodate riders, remove these alterations immediately as this can result in serious injury or death. A "NO RIDERS" decal should be in place. Please request these from your dealer or use the web to contact and request them from Fort Miller FAB3 Corp. (518)-584-4400 or <u>www.fmfab3.com</u>.

# A WORD ABOUT SAFETY:

The TARCO® Lowlander Spreader described in this manual can be operated during conditions with bad weather such as snow & ice conditions. Due to these adverse operating conditions it is important that you the operator use good safety practices at all times to protect yourself, co-workers, and others when operating this machine.

It is not practical or possible to warn you about all the hazards associated with the operation and maintenance of this machine. You must use your own good judgement supplemented with the information found on the safety decals, instructions in this manual, your employer's safety programs, safety codes, local, state/provincial, and federal laws, rules and regulations.

When performing maintenance on the machine, trouble shooting the operations of the machine, loading or unloading the machine with material or operating the machine observe & obey all safety decals on the machine and warnings listed in the manual. Failure to do this could result in serious injury or death to you and/or others.

Remember at all times that as the operator, you are responsible for the safe operation of this equipment and are responsible for the safety of others. Good safety practices not only protect you but also protect the people around you.



#### A WARNING SYMBOL INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN SERIOUS INJURY OR DEATH



**WARNING DO NOT** operate unit without wearing proper safety equipment as described in this manual.

**WARNING** DO NOT operate, maintain or repair this unit without fully reading and understanding ALL aspects of this manual.

WARNING DO NOT lubricate, make any adjustment or repairs before proper LOCK OUT/TAG OUT is performed.

WARNING DO NOT operate the unit while under the influence of alcohol, drugs, or any medication that could impair operating abilities.

**WARNING DO NOT** operate the unit with ANY guards or safety devices broken, missing, or inoperable.

**WARNING DO NOT** operate the unit without fully inspecting the unit for any damage or leakage.

**WARNING DO NOT** use equipment that is not safe.

**WARNING DO NOT** operate the unit if all function are not in good working order.

**WARNING DO NOT** operate unit in a state of disrepair.

**WARNING DO NOT** ride, sit or stand on the unit while in use.

WARNING DO NOT place hands or feet near moving or rotating parts.

**WARNING DO NOT** allow personnel to ride anywhere, except in the cab, when the unit or vehicle is in operation.

**WARNING DO NOT** modify the unit for any reason to allow for riders.


**WARNING DO NOT** smoke or weld near the unit.

**WARNING DO NOT** leave machine running unattended.



```
A WARNING SYMBOL INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN
SERIOUS INJURY OR DEATH
```





**WARNING DO** keep the spreader and surrounding area clear of personnel and property while in operation.

**WARNING** Use care when mounting and dismounting the spreader from the truck.

**WARNING DO** keep the spreader and components in proper working condition.

**WARNING** DO observe and obey all warning and safety decals displayed on the machine.

**WARNING** DO always use a funnel for filling fuel tank and do not over fill the tank. Always be sure the engine is off when re-

fueling.

**WARNING** DO when any mechanism, or other moving part becomes jammed or clogged use proper LOCK OUT/TAG OUT procedures to lock out all power sources before attempting to clear blockage.



# DANGER INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN SERIOUS INJURY OR DEATH

**ADANGER** The auger and spinner drive assemblies transmit great amounts of power and are hazardous when in operation. All maintenance, inspections, or operator adjustments must be made with the power off, and proper LOCK OUT/TAG OUT procedures must be followed. All safety guards and shields must be reinstalled prior to use.

**A DANGER** When any mechanism, the auger, spinner assembly, or other moving part becomes jammed or clogged use proper LOCK OUT/TAG OUT procedures to lock out all power sources before attempting to clear blockage

#### LOWLANDER SPREADER

#### TABLE OF CONTENTS

Cover Page	
Important Safety Information	2
Table of Contents	10
Lowlander Spreader	11
Decal Location	12
Decal Identification	17

3

2

**WARNING** KEEP LOOSE CLOTHING, HANDS AND FEET AWAY FROM THE AUGER OPERATING AREA. THE AUGER IS A SPINNING **BLADE IT CREATES PINCH POINTS, AND COULD CAUSE** ENTANGLEMENT OF CLOTHING PULLING THE OPERATOR IN TO THE MACHINE. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY OR DEATH.

5

**WARNING** STAY CLEAR OF THE SPINNER OPERATING AREA. THE SPINNER THROWS MATERIAL AT A HIGH RATE OF SPEED **OPERATORS CAN BE STRUCK BY THE MATERIAL. FAILURE TO DO** SO COULD RESULT IN SERIOUS PERSONAL INJURY OR DEATH.


LOWLANDER SPREADER


ASSEMBLY

BOM ID	Description	Qty
1	TRUCK MOUNTING HARDWARE	1
2	TAILGATE SPREADER ASSEMBLY	1
3	AUGER	1


BOM ID	Description	Qty
4	FRONT TROUGH	1
5	SPINNER ASSEMBLY	1

	DECALS		
BOM ID	JDENumber (config)	Description (config)	Qty
1	37486	SERIAL TAG 1-1/2" X 7" SS	1
2	27542	DECAL-DANGER BEFORE	1
3	27507	DECAL - SAFETY FIRST	1






BOM ID	JDENumber (config)	Description (config)	Qty
1	27713	DECAL - DO NOT OPERATE THIS	1
2	27507	DECAL - SAFETY FIRST	1



BOM ID	JDENumber (config)	Description (config)	Qty
1	27561	DECAL-DANGER-KEEP HANDS AND	1
2	27546	DECAL- WARNING DANGER STAY	1



BOM ID	JDENumber (config)	Description (config)	Qty
1	27517	<b>DECAL - CAUTION-READ &amp; FULLY</b>	1

#### **DECAL IDENTIFICATION**





**IF NOT FOLLOWED SEVERE INJURY, DEATH OR EQUIPMENT DAMAGE COULD RESULT** LOCATION DETAIL SEE PAGE 12 ITEM 3 LOCATION DETAIL SEE PAGE 13 ITEM 10 LOCATION DETAIL SEE PAGE 14 ITEM 2

## JDE# 27507 (7500-36) QTY=3

#### 

Before attempting to operate this machine or work on it, be sure you have familiarized yourself with the instruction manuals and understand them. <u>NEVER</u> attempt to lubricate, inspect, or repair any component while power source is in operation or while it is engaged. Failure to follow these instructions could result in serious personal injury or equipment damage.

# **WARNING** 📩 🛕

**IF NOT FOLLOWED SEVERE INJURY, OR EQUIPMENT DAMAGE COULD RESULT** LOCATION DETAIL SEE PAGE 12 ITEM 2

# JDE# 27542 (7500-43) QTY=1



rates of speed. Make sure the power source for the entire spreader has been shut down and locked out before entering the spinner operating area. Failure to do so could result in serious personal injury.



**IF NOT FOLLOWED SEVERE INJURY COULD RESULT** LOCATION DETAIL SEE PAGE 15 ITEM 2

# JDE# 27546 (7500-45) QTY=1



#### JDE# 27561 (7500-87) QTY=3



IF NOT FOLLOWED SEVERE INJURY, COULD RESULT

LOCATION DETAIL SEE PAGE 13 ITEM 7 LOCATION DETAIL SEE PAGE 13 ITEM 9 LOCATION DETAIL SEE PAGE 15 ITEM 1



**COMPANY BRAND** LOCATION DETAIL SEE PAGE 13 ITEM 2

#### JDE# 27493 (7500-14R) QTY=1



**COMPANY LOGO** LOCATION DETAIL SEE PAGE 13 ITEM 4

## **AWARNING**

DO NOT OPERATE THIS MACHINE BEFORE READING THE OPERATION & MAINTENANCE MANUAL FOR THIS MACHINE.

IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY

### JDE# 27713 (7500-98) QTY=2

# 

**IF NOT FOLLOWED SEVERE INJURY, DEATH OR EQUIPMENT DAMAGE COULD RESULT** LOCATION DETAIL SEE PAGE 13 ITEM 6 LOCATION DETAIL SEE PAGE 14 ITEM 1

# **AWARNING**

Read and fully understand Operating and Maintenance Manual before attempting to work on this machine.

MOVING PARTS INSIDE: Do not remove this cover until machine power source has been shut down failure to follow this safety precaution could lead to personal injury or damage to equipment.

## **WARNING** 📩 🛕

**IF NOT FOLLOWED SEVERE INJURY, DEATH OR EQUIPMENT DAMAGE COULD RESULT** LOCATION DETAIL SEE PAGE 13 ITEM 1 LOCATION DETAIL SEE PAGE 13 ITEM 5 LOCATION DETAIL SEE PAGE 16 ITEM 1

# JDE# 27517 (7500-41) QTY=3

# LOWLANDER

MACHINE NAME LOCATION DETAIL SEE PAGE 13 ITEM 8

## JDE# 48600 (48600) QTY=1

www.fmfab3.com

**CONTACT INFORMATION** LOCATION DETAIL SEE PAGE 13 ITEM 3

JDE# 29761 (7500-101) QTY=1